

Zoom/Enlarge/Reduce

Reduction and enlargement can be performed using the "Zoom" portion of the copy menu (Highlighted below).

You can use this portion of the menu to change the amount of zoom applied in the copy process. This can be done manually or with preset zooms for popular paper sizes (Letter to Legal enlarge, Ledger to Letter reduce, etc) Touching "Zoom" near the bottom of the menu will give you more granular zoom options like independent X and Y zoom.

Adjust these settings to find the proper configuration for the output desired.

